

- 1 Stopwatch 1/10 sec. | Stoppuhr 1/10 Sek.
- 2 Stopwatch seconds | Stoppuhr Sekunden
- 3 Stopwatch minutes | Stoppuhr Minuten
- I Crown normal position | Krone Normalpos.
- II Date setting | Datumseinstellung
- III Time setting | Zeiteinstellung
- A Stopwatch start-stop | Stoppuhr Start-Stopp
- B Stopwatch reset | Stoppuhr Zurücksetzen

Battery | Batterie

SR 920 SW

Case Diameter | Gehäusedurchmesser

44 MM

Case thickness | Gehäusestärke

11 MM

Movement | Uhrwerk

TMI VD57C

Water resistance | Wasserbeständigkeit

3 ATM

Weight | Gewicht

~ 123 g

Band width | Armbandbreite

22 MM

Materials used | verwendete Materialien

stainless steel: Case, Backcase, Buckle, Wristband

Edelstahl: Gehäuse, Gehäuserückseite, Verschluss, Armband

Wood: Brezel, Wristband

Holz: Lünette, Armband

Copper | Kupfer: Dial | Ziffernblatt

Stopwatch

This watch includes a stopwatch function which you can start and stop by pressing button A, and reset with button B. You can adjust the second (2) and minute (3) hand when using the stopwatch function by pulling the crown out to position III (until the clock stops), then use button B to adjust the hands.

Stoppuhr

In diesem Modell ist eine Stoppuhr integriert, welche sich mit der Taste A starten und anhalten und mit der Taste B zurückstellen lässt.


Den Sekunden- (2) und Minutenzeiger (3) der Stoppuhr kannst du einstellen, indem du die Krone auf Position III herausziehst bis die Uhr komplett stillsteht. Nun kannst du mit der Taste B die Zeiger verstellen.

Adjustment Wristband:

<https://www.holzspecht.com/en/adjust-wristband/>

Armband anpassen:

<https://www.holzspecht.com/armbandlaenge-einstellen/>



Accuracy ± 20 sec/month
Genauigkeit ± 20 sek/Monat



Battery Life 2 Years
Batterie Lebensdauer 2 Jahre